



Evolvable Cryogenics (eCryo) Project Technology Workshop with Industry

Engineering Development Unit (EDU) Workshop

Cryogenic Isolation Valves

Becky Crownover


JTI, Jacobs ESSSA Group
Product ID: ESSSA-FY15-00266
Contract: NNM12AA41C
Task Order: ES.24.05.R33.CRYO.000.0000

JACOBS
ESSSA Group

Background – CPST Needs a Valve





- CPST GTA needed a cryogenic isolation valve that met the following requirements:
 - Low Cost
 - Low Leakage
 - Low Heat Input
 - Operate in Vacuum Environment
 - Hydrogen Compatibility
- Initial valve trade study covered everything from a flight-like valve to an in-house valve design to COTS valves.
 - Most cost-effective option was to use a proven COTS valve.
 - A Swagelok® U-Series valve with a PCTFE Stem tip for use with LH2 was chosen. This valve has a welded bellows which in combination with the PCTFE stem tip provides lower risk of external and internal leakage.



Background – CPST Needs a Valve



- Another trade study was conducted to select an actuator for the valve.
 - Stepper motors were considered but eliminated due to cost and complexity of control system.
 - A flight-like design was also considered, but eliminated due to low TRL level and cost.
 - An in-house pneumatic bellows actuator was chosen.
 - PRO: Lowest cost option.
 - PRO: No heater required, so low heat input option.
 - CON: Requires additional facility valve to control pneumatics (open/close valve).



Background – Actuator Design



- Key Actuator Design Parameters

- Performance

- Min. Stroke Length: 0.100 in.
 - Max. Stroke Time: 0.500 seconds
 - Minimum Stroke Time Limit: 0.250 seconds
 - Cycle Life: 2,000

- Environments

- Maximum Temperature: 100° F
 - Minimum Temperature: -400° F
 - Max. External Pressure: 15 psia
 - Min. External Pressure: 0 psia

- Interfaces

- Mounting Interface: 1/4"–20 UNC on 2" bolt circle
 - Valve to Actuator Shaft Interface: 5/8"–24 UNF



- Safety

- Pressure Boundary Burst Factor (excludes bellows): 4
 - Pressure Boundary Burst Factor, Bellows: 1.5
 - Pressure Boundary Proof Factor (excludes bellows): 1.5
 - Pressure Boundary Proof Factor, Bellows: 1.25

Background – Actuator Design continued...



- Actuator Concept of Operation
 - Spring and bellows spring load provides opening force.
 - GHe provides closing force via external pressure on bellows.
 - Passive state is open, but can be made to “fail closed” on loss of power by using a solenoid that provides GHe pressure to actuator in unpowered state.
 - Actuator GHe fills and vents through supply tube on top of actuator.
 - Inner bellows open to external environment via vent port.



Background – Actuator & Valve Testing




- Development Testing
 - Actuator Bellows
 - Pneumatic Proof Testing
 - Helium Leak Check
 - Burst Test
 - Actuator Housing
 - Pneumatic Proof Testing
 - Helium Leak Check
 - Burst Test
 - Stroke Length Test
 - Force Output Test
 - Confirm Actuator to Valve Interfaces
 - Cycle Life Testing
 - Actuator Bellows
 - Valve Internal Leakage
 - Valve Flow Coefficient Test
- Characterization Testing at Ambient Temperature
 - Flow Rate and Pressure Drop Test
 - Cycle Verification and Response Time Test
 - Internal Forward Leakage at Low Actuator Pressure
 - Force Balance Verification
 - Internal Forward Leakage at High Actuator Pressure
- Acceptance Testing at LH2 Temperature
 - Cycle Verification and Response Time Test
 - Internal Forward Leakage at Nominal Actuator Pressure
 - ≤ 492 sccm


Background – Valve Assembly





Acceptance Test and EDU Configuration




GTA Configuration



Background – CPST GTA Schematic



Background – CPST EDU Schematic



CPST EDU Testing



- The valves experienced some cycles during characterization and acceptance testing prior to being installed into the CPST EDU test configuration.
- Since their installation into the CPST EDU test configuration, two rounds of testing have occurred.
 - LN2 Testing: 1 day
 - LH2 Testing: 20 days
- Valve Cycle Count
 - The valve cycle life is governed by the actuator cycle life limit of 2,000 cycles.

Valve	Cumulative Cycles prior to LH2 Test	Cycles Accumulated During LH2 Test	Cumulative Cycle Count	Cycle Life Remaining
V-1401 Fill/Drain	108	32	140	1860
V-1444 Bottom Press	107	14	121	1879
V-1402 AJ TVS VJ	109	53	162	1838
V-1404 LAD TVS VJ	109	25	134	1866

- The remaining valve cycles are adequate on all four valves to allow further testing with the EDU hardware.

CPST EDU Testing continued...



- Actuation Pressure During LH2 Testing
 - All actuators are fed from the same supply, so they should not differ from each other greatly (variation due to pressure drop along different line lengths and calibration).
 - Nominal Actuation Pressure: 325 psig
 - Should not exceed 350 psig

Valve	Maximum Actuator Pressure	Date / Test Day / GMT Day
V-1401 Fill/Drain	331.723 psig (P5019)	19 June / Test Day 8 / GMT Day 170
V-1444 Bottom Press	327.139 psig (P5036)	19 June / Test Day 8 / GMT Day 170
V-1402 AJ TVS VJ	328.759 psig (P5020)	12 June / Test Day 1 / GMT Day 163
V-1404 LAD TVS VJ	325.345 psig (P5022)	11 June / Pre-Test / GMT Day 162



- None of the cryogenic isolation valve actuators were exposed to excess pressure.

CPST EDU LH2 Testing Data Observations

Fill/Drain Valve Performance During Tank Loading



- Fill/Drain Valve Performance During Tank Loading
 - LN2 load time to 90% level on the vertical temperature rake was 6 hours, 4 minutes.
 - Removal of the Fill/Drain Valve was evaluated; decided to leave the valve in place.
 - LH2 load time from empty to 80% level on the vertical temperature rake was 1 hour, 47 minutes.
 - LH2 topping time from 70% to 90% was 27 minutes.
 - A cold helium purge was used prior to initial fill, but effect was minimal on bulk tank temperature.
 - Full size data plots are included in Backup.





CPST EDU LH2 Testing Data Observations

Valve Actuation Pressure



Data Plot: 6/13 Valve Actuator Pressures and AJ Mixer Pump Voltage

Data Plot: 6/19 Valve Actuator Pressures and AJ Mixer Pump Voltage



Noticeable shift in all actuator pressure data when AJ Mixer Pump is running, not a real pressure change.

This instance coincides with the AJ Mixer Pump being run at 40 Hz when it had a voltage cutoff.


CPST EDU LH2 Testing Data Observations

Valve Internal Leakage



- Valve Internal Leakage
 - V-1401: Fill/Drain Valve
 - There was suspicion of leakage noted in the 15 June Daily Activity Log. Pressure was vented between V-1401 and facility valve ROV-20-618, or dropped from 0.24 to 0.14 psig. The facility pressure measurement (P3111) then rose to about 0.2 psig.
 - The data plot below includes data for three days starting on 15 June and shows that the facility pressure and temperature (T3222) measurements cycle with the temperature of the day. The pressure values range from +0.24 to -0.38 psig daily.
 - If there is a leak, it is very small and self-limiting. Further evaluation in work.

Pressure fluctuations follow daily temperature cycle. Downstream side of valve interfaces with outside of chamber.




CPST EDU LH2 Testing Data Observations

Valve Internal Leakage continued...



- Valve Internal Leakage
 - V-1444: Tank Bottom Pressurization Isolation Valve
 - The data plot below includes data for three days starting on 15 June and shows that the EDU pressure measurement cycles with the temperature of the day. Although not shown, the facility pressure (P3272) and temperature (T3271) measurements also show this behavior.
 - There is no indication of a substantial leak. Further evaluation in work.
 - V-1402: Axial Jet TVS Visco Jet Inlet Isolation Valve
 - V-1404: LAD TVS Visco Jet Inlet Isolation Valve
 - The downstream side of these valves are exposed to the 15-ft vacuum chamber. There was no pressure build-up in the 15-ft vacuum chamber suggesting these valves did not leak.

Pressure fluctuations follow daily temperature cycle. Upstream side of valve interfaces with outside of chamber.






CPST EDU LH2 Testing Data Observations

Valve Temperature Measurements



- Valve Body and Actuator Temperature Measurements
 - V-1401: Fill/Drain Valve
 - Body Temperature Measurement: D5535
 - Actuator Temperature Measurement: T5536
 - V-1402: Axial Jet TVS Visco Jet Inlet Isolation Valve
 - Actuator Temperature Measurement: D5428
- Plots of the data for the duration of the test are included in Backup.
- There was a thermal model created of the valve to assist in determining an appropriate purge rate. This data could be compared to that model.
- No conclusions can be drawn from this data at this time.



Conclusions



- The cryogenic isolation valves operated as expected, allowing the related Test Objectives and Success Criteria to be met.
 - Valves opened/closed when commanded.
 - The pressure supplied to the actuators was nominal.
 - The valves retained LH2 in the storage tank with acceptable internal leakage levels.
 - The remaining valve cycles are adequate on all four valves to allow further testing with the EDU hardware.
 - Allowable cycles based on actuator design: 2,000

Valve	Cumulative Cycle Count	Cycle Life Remaining
V-1401 Fill/Drain	140	1860
V-1444 Bottom Press	121	1879
V-1402 AJ TVS VJ	162	1838
V-1404 LAD TVS VJ	134	1866



Cryogenic Isolation Valves Back-up Charts

Acronyms & Abbreviations



°	Degree
AJ	Axial Jet
COTS	Commercial Off The Shelf
CPST	Cryogenic Propellant Storage and Transfer
eCryo	Evolvable Cryogenics
EDU	Engineering Development Unit
F	Fahrenheit
GHe	Gaseous Helium
GMT	Greenwich Mean Time
GTA	Ground Test Article
Hz	Hertz
in.	Inch
K	Kelvin

LAD	Liquid Acquisition Device
LH2	Liquid Hydrogen
LN2	Liquid Nitrogen
PCTFE	Polychlorotrifluoroethylene
psia	Pounds Per Square Inch Absolute
psig	Pounds Per Square Inch Gauge
PTFE	Polytetrafluoroethylene
sccm	Standard Cubic Centimeters per Minute
SS	Stainless Steel
TRL	Technology Readiness Level
TVS	Thermal Venting System
UNC	Unified National Standard Coarse Thread
UNF	Unified National Standard Fine Thread
VJ	Visco Jet


CPST EDU LH2 Testing Data Observations

Fill/Drain Valve Performance During Tank Loading



Data Plot: 5/29 LN2 Cold Shock V-1401 and Vertical Temp Rake

Total LN2
Load Time
to 90% Level
6 hr, 4 min




9:11:21AM 07/23/2014

CPST EDU LH2 Testing Data Observations

Fill/Drain Valve Performance During Tank Loading



Data Plot: 6/12 LH2 Test V-1401 and Vertical Temp Rake



9:34:13AM 07/23/2014


CPST EDU LH2 Testing Data Observations

Valve Actuation Pressure



Data Plot: 6/13 Valve Actuator Pressures and AJ Mixer Pump Voltage

Noticeable shift in all actuator pressure data when AJ Mixer Pump is running, not a real pressure change.




CPST EDU LH2 Testing Data Observations

Valve Actuation Pressure



Data Plot: 6/19 Valve Actuator Pressures and AJ Mixer Pump Voltage

Noticeable shift in all actuator pressure data when AJ Mixer Pump is running, not a real pressure change.



This instance coincides with the AJ Mixer Pump being run at 40 Hz when it had a voltage cutoff.


CPST EDU LH2 Testing Data Observations

Valve Internal Leakage – Fill/Drain Valve



Data Plot: 6/15 – 6/17 Pressure & Temperature Data for V-1401

Pressure fluctuations follow daily temperature cycle. Downstream side of valve interfaces with outside of chamber.




CPST EDU LH2 Testing Data Observations

Valve Internal Leakage – Tank Bottom Press Iso Valve



Data Plot: 6/15 – 6/17 Pressure & Temperature Data for V-1444

Pressure fluctuations follow daily temperature cycle. Downstream side of valve interfaces with outside of chamber.




CPST EDU LH2 Testing Data Observations

Valve Internal Leakage – Instrumentation Location




To Storage Tank - AFT
(submerged) Diffuser

TS300 GHe
Facility Supply



CPST EDU LH2 Testing Data Observations

Valve Temperature Measurements




CPST EDU LH2 Testing Data Observations

Valve Temperature Measurements



Data Plot: 6/12 – 6/20 V-1401 & V-1402 Valve Body/Actuator Temperatures




CPST EDU LH2 Testing Data Observations

Valve Temperature Measurements continued...



Data Plot: 6/21 – 6/25 V-1401 & V-1402 Valve Body/Actuator Temperatures

Pressurization
Testing on
6/23 & 6/24



CPST EDU LH2 Testing Data Observations

Valve Temperature Measurements continued...



Data Plot: 6/26 – 7/7 V-1401 & V-1402 Valve Body/Actuator Temperatures

LAD Outflow
Testing on
6/30 & 7/1

